

# OFF CENTER PLATTER

## Preparing the blank

1. Size matters - What can your lathe handle?
2. Grain direction
3. Where will you decide to "offset" it? The screw holes
4. Drill Holes for Screw Chuck

## Cutting

1. Mount Blank & True Up Blank - Bottom Not Necessary
2. Turn recess in middle for a scroll chuck
3. Draw the guide circle on bottom and turn cylinder
4. Flatten and sand underside of rim
5. Turn Around and Flatten top
6. Turn any embellishments on this axis now
7. Sand top - May sand more later
8. Turn around and Mount on off center hole
9. Turn off old bottom and turn a recess at new center
10. Form the "bowl" and foot
11. Care needed when blending on the rim underside - Explain?
12. Turn around and form the "bowl"
13. Sand and Done